

Bachmann Class 03 Sounds and Function List

F1 - Sound On/Off

F2 - Brake

F3 - Horn (Playable)

F4 - Two-Tone Horn

F5 - Light Engine Mode

F6 - Engine Idle

F7 - Shunting Mode

F8 - Cold Start

F9 - Flange Squeal (Speed Related)

F10 - Cab Light

F11 - Buffering Up

F12 - Coupling Sounds

F13 - Low Toot

F14 - High Toot

F15 - Windscreen Wipers

F16 - Dispatch Whistle

F17 - On - Driver's Door Opening / Off - Driver's Door Closing

F18 - Fade All Sounds

F19 - On - "Draw up" / Off - "6t, 4t, 2t, Whoa!"

F20 - "Squeeze Up"

F21 - On - "Going Under" / Off - "Clear to go under"

F27 - Volume Down

F28 - Volume Up

Analogue Users: Please note that normal load running sounds and any other automatic or randomised sounds will also operate when this model is used on analogue control (DC) straight from the box!